

DSLR Camera Bag



SKU:

EAN:

FEATUES

The Edis DSLR Camera Bag Tablet Compartment. Don't worry about leaving your tablet or e-Reader at home our large DSLR camera/gadget bag features a padded slot that is able to fit an iPad mini, Kindle Fire, Google Nexus 7, and other small devices. Additional pockets in the front offer a space for a cell phone and other electronics and accessories. With Bright orange color and large storage space for all kinds of accessories. Protect your camera and all other equipment safely. The soft neck strap with adjustable toggle makes carrying comfortable and the durable and waterproof material with a strong zipper makes the carry bag extremely safe. Our multi-space design, with mesh zipper, a variety of compartments makes it easy and safe to find and store your camera and accessories. A secure passport pocket situated nearest you is the perfect place for passports, cash, or other important documents when you are on the move.



DSLR CAMERA BAG

Material	polyester
Size	External dimensions: 12" x 7" x 9" (LxWxH) Internal dimensions: 10" x 5" x 7" (LxWxH)
Features	Store, carry and protect your camera equipment
Packing	Each bag into a PE bag